

alloy stemraiser

installation:

- 1) Ensure you have the correct size. (1 1/8")
- 2) Make sure side bolts on Alloy Stem Raiser are loose and mount raiser to steerer, pushing down to ensure snug fit.
- 3) Tighten threaded bolt to "star-fangled nut" inside the steerer tube.
Ensure a snug fit so that fork steerer isn't wobbly. Do not overtighten, as headset bearings may become damaged.
- 4) Tighten side bolts to snug fit so that you cannot rotate it. Do not overtighten.
- 5) Attach stem to upper portion of Alloy Stem Raiser.
Center stem so that bars are in proper alignment and tighten stem the Stem Raiser.
Do not overtighten.
- 6) Screw on dust cover cap and get out and ride!

⚠ WARNING: Incorrect installation could result in an accident causing serious injury. Installation should only be performed by a properly trained bicycle technician.